

FLASH CODE/SEQUENCE	FAULT	IMPACT ON POWER CHAIR	NOTES
FLASH CODE #1 *__*__*	DX Module Fault	Will drive (slowly).	An auto download has occurred. The Europa is not correctly programmed. The connection between the power module and the joystick module may be faulty. Refer to FLASH CODE #1 - DX Module Fault.
FLASH CODE #2 **__**__**	DX Accessory Fault	Drive inhibited.	The accessory module (CLAM) has a fault. Refer to FLASH CODE #2 - DX Accessory Fault.
FLASH CODE #3 ***__***__***	Left Motor (or connection) Fault	Drive inhibited.	The connection between the power module (4) and the left motor (8) is either open or is shorted or the motor itself is shorted. Refer to FLASH CODE #3 - Left Motor (or connection) Fault.
FLASH CODE #4 ****__****__****	Right Motor (or connection) Fault	Drive inhibited.	The connection between the power module (4) and the right motor (9) is either open or is shorted or the motor itself is shorted. Refer to FLASH CODE #4 - Right Motor (or connection) Fault.
FLASH CODE #5 *****__*****__*****	Left Park Brake (or connection) Fault	Drive inhibited.	The connection between the power module (4) and the left park brake is either open or is shorted or the motor brake itself is shorted. Refer to FLASH CODE #5 - Left Park Brake (or connection) Fault.
FLASH CODE #6 *****__*****__*****	Right Park Brake (or connection) Fault	Drive inhibited.	The connection between the power module (4) and the right park brake is either open or is shorted or the motor brake itself is shorted. Refer to FLASH CODE #6 - Right Park Brake (or connection) Fault.
FLASH CODE #7 *****__*****__*****	Low Battery Fault	Drive inhibited. (May Stop Slowly.)	Battery voltage has fallen below 17VDC. Refer to FLASH CODE #7 - Low Battery Voltage.
FLASH CODE #8 *****__*****__*****	Over Voltage Fault	Drive inhibited.	The battery voltage has exceeded 32VDC. Refer to FLASH CODE #8 - Motor Volts Error.
FLASH CODE #9 *****__*****__*****	CANL Fault	Will drive (slowly).	The DX Bus cable (2) has a short or an open. Refer to FLASH CODE #9 - CANL Fault.
FLASH CODE #10 *****__*****__*****	CANH Fault	Will drive (slowly).	The DX Bus cable (2) has a short or an open. Refer to FLASH CODE #10 - CANH Fault.
FLASH CODE #11 *****__*****__*****	Stall Timeout Fault	Drive inhibited.	The motor has been close to or at the programmed current limit. Refer to FLASH CODE #11 - Stall Timeout Fault.
FLASH CODE #12 *****__*****__*****	Module Mismatch	Drive inhibited.	There is an incompatibility between the DX modules in the system. Refer to FLASH CODE #12 - Module Mismatch.

* = System Status LED Flash

— = Pause (2 seconds)

Table 1 . Jazzy 1121 Europa Flash Codes