

- | | |
|---------------------------|-----------------------------------|
| ① VSI CONTROLLER | ⑥ BATTERY CHARGER |
| ② POWER INTERFACE HARNESS | ⑦ CHARGER POWER INTERFACE HARNESS |
| ③ CIRCUIT BREAKER HARNESS | ⑧ RIGHT MOTOR |
| ④ AMMETER | ⑨ LEFT MOTOR |
| ⑤ CHARGER INHIBIT HARNESS | |




Diagram 1. Jet 3/10 Ultra Troubleshooting Key